
GentleJet

Automatic Foam Soap Dispener


SimpleFoam

User Manual




Please read this instruction carefully before using and keep it properly for further using.

Product Presentation




Directions

①



Charge with Type-C until the White light always on

②




Take out the main part

③



Pour foam hand sanitizer into the bottle, not exceed the max line

④



Aim the main part to bottle and screw downward until it is fixed


Directions

⑤



Press and hold the touch switch for 2S on / off

⑥



Hands to the induction area, you can get rich foam.

⑦



Rub the soap to foam fully

⑧





Rinse hands with water

Automatic cleaning mode:
In the standby state, double click the button, the indicator blue light continuously flashes, bubble is emitted continuously for 20s. Press the button if you need to stop cleaning in advance.

Specifications

Product Name：Automatic Foam Soap Dispener
Item No： SimpleFoam
Materials：ABS
Size：115x80x144mm
N.W：About 260g (without hand sanitizer)
Working Temperature:5～40
Working Humidity:0～95%RH
Rated Voltage：DC 3.7V
Rated Current：0.65A
Rated Power：2.4W
Charging Voltage：DC 5V
Charging current：0.8A
Executive Standard：GB4706.1-2005、Q/JSSY 002-2022
Waterproof level：IPX5
Sensing Distance：0～5CM
Single liquid output：1.0g(high)，0.6g(low)
Liquid Type:foam hand sanitizer
Capacity：300mL
Installation method: tabletop
Working life: ≥ 50000 times

Indicator light indication

On	White light on
Off	Red light flash 2times
High Grade	White light on
Low Grade	Green light on
Charging	Red light always on
Full charge	White light always on
Battery low	Red light on when bubbling
Auto-cleaning mode	Blue light keeps flashin
Induction area is blocked	the blue/green light flash 3mints alternately.
Low voltage automatic shutdown	Red light flash 5 times

Maintenance

1、When cleaning,please use a wet towel to gently wipe the surface of the machine in the shutdown state.

2、Recommended that the machine be used frequently to achieve the best state, and it is necessary to inducing at least once per month if not using for a long time.

3、Recommended to charge disapenser every 2-3 months to extend the battery life if it is not used for a long time.

4、Store the soap dispenser in a cool place away from direct sunlight or heat.

Troubleshooting

No	Fault Phenomenon	Fault Cause	Solutions
1	Unable to switch on	Batteries without power	Charge
2	Indication light doesn't shine	Not turned on the machine	Turn on it correctly
3	No liquid outflow	Run out of liquid	Add liquid
		Machine fault	Contact us
4	the blue/green lights flash alternately	Countertop reflection	Put a black rubber pad under the machine.
		Something blocking the sensor	wipe the sensor and restart

Cautions

1、Do not immerse the machine into water or rinse it directly with water to avoid short circuit.

2、Do not tilt or squeeze bottle and exceed the max line when pouring hand sanitizer. Keep the bottle clean before using.

3、It is strictly forbidden to use or add viscous liquids containing granules, powders, emulsions, etc. Avoiding machine failure. wiping

4、When there is liquid in the machine,do not put the machine down.

5、Do not block the bubble outlet with your hands or foreign objects.

6、When there is a foreign object on the sensor for 5 seconds,the blue/green lights flash alternately. At this time,shut down the machine,wipe the sensor or remove the occlusion and restart. The blue & green lights blink 3 mints alternately and will automatically shut down.

7、When the power is low, the red light will on after sensing, reminding to charge in time.

8、It is strictly prohibited to use a charger that does not match this machine for charging, otherwise it will cause the battery to fire or esplode.

9、There is no need to shut down when normal use, and it will automatically stand by when not working.

10、This machine is a touch button, the sensitivity of the button may be affected when there is water droplets on the button, pls wipe and clean it before operation.

11、If disapenser is not used for a long time, the hand sanitizer in the pipeline is easy to dry up, resulting in no foam induction. At this time, you can try to double-click the power button in the startup state to enter the cleaning mode, and the continuous pumping can effectively solve the problem of foam.

12、Children should use it under adult supervision to avoid spraying liquid soap into eyes and ingestion.

Warranty Description

The after-sales service of automatic soap dispenser is as follows:

1.Within 7 days from the day you signed for the product,the malfunction of the product listed in the malfunction table is determined by the after-sales service center,and you can enjoy free return or replacement service.

2.Within 8-15days from the next day of your signing,the malfunction of the product listed in the malfunction table is determined by the after-sales service center,and you can enjoy free replacement service.

3.Within 12 months from the next day of your signing,this product has a failure listed in the malfunction table is determined by the after-sales service center,and you can enjoy free maintenance.

Malfunction Table	
Automatic Soap Dispenser	Unable to switch on/off
	Indicator light is not on
	No foam outflowing

Non-warranty regulations

1.Unauthorized maintenance,misuse,collision,negligence,abuse,injection,alteration, incorrect use of non-product accessories, or tear, alter the label, anti-counterfeiting marks.

2.The three guarantees period has been exceeded.

3.Inconformity with the performance listed in the malfunction table.

4.Product and its accessories have the performance failure listed in malfunction table due to human factors.