95*210mm

TROUBLESHOOT METHODS

Issue	Troubleshoot method
No misting	1. Check the power supply. 2. Check the "Misting hole" to see if the device is pumping air. 3. Ensure that the top part of the diffuser is installed to the device correctly. 4. Ensure that the bottle is tightened into the diffuser head.

WARRANTY

Your device comes with limited warranty. Please ensure that you have proof of purchase in case a claim arises. Please note that the warranty is non-transferable.

The following will not be covered under warranty:

- Damage caused by accidents or fire.
- Failure to use device properly.
- If the device is repaired by a non-authorized dealer.
- Third party parts used in the machine.

MAINTAINANCE

The scent diffuser should be cleaned every 1-2 months to ensure optimal performance. To clean the inner workings of the device, please follow these steps:

1. Take the upper part of diffuser, and fill rubbing alcohol to the bottle.
2. Install the upper part with bottle to diffuser.
3. Turn on the diffuser and keep working 15 minutes, to ensure alcohol go through the whole device.
4. Remove the electric cord from the diffuser and keep the diffuser in an upright position. Wipe the device with a damp cloth to remove oil stains and fin-gerprints. Don't use any harsh or abrasive to clean the device.

Made in China


Equipment Component Instruction



SAFETY

1. The diffuser should be used in an upright position always.
2. Do not tilt the diffuser as oil can spill inside and damage the device.
3. Do not use the device with any other power cords. Please use the original power cord that comes with diffuser. Position the power cord to prevent tripping hazard.

REPLACING THE NOZZLE




1. Unplug the diffuser and remove fragrance oil bottle, pull out the small tube. Using tweezers wiggling the nozzle and pull out the black nozzle gently.



2. Replace it with a new nozzle and ensure the nozzle is pressed very firmly into the top of the diffuser. Then reinsert the tube to the nozzle.

Note:
It is very important that you put the tube into the correct position of the nozzle, otherwise the device will not diffuse scent. Within the nozzle there is a small round tube holder that the tube needs to be firmly secured into. TIP: If you have difficulty to see the tube holder in the nozzle, hold a flashlight into the nozzle to increase visibility.

Scent Diffuser



User Manual

SCENT DIFFUSER INTRODUCTION

Our scent diffuser utilizes the latest cold-air diffusion technology which turns any of our hotel-inspired fragrance oil into a dry nano mist, allowing the scent to stay idle in the air for much longer while providing superior, long-lasting coverage. It uses no water or heat and preserves the therapeutic properties of our fragrance oils without altering their smell.

Uses advanced atomization technology which makes it residue free and safe for pets, children, artwork, and furniture.

This model comes with an easy to use remote control.



TECHNICAL FEATURES

Model.: BD900 | Power: 10W | Voltage: 5V 2A | Noise: <38 db
Coverage: 1,000 sq.ft | Oil bottle capacity: 120ml

- The package includes the diffuser with empty 120mL bottle, remote controller, USB cable, adapter, metal hook, spare nozzle, seal rubber ring, and user manual.
- The remote controller is designed for convenient adjustment of fragrance concentration levels to suit your preferences, as well as setting the desired operating duration for the device.
- Please follow the instructions set out in this manual and use the device correctly.




USING GUIDE




Step 1: Remove Empty Bottle

- Take the upper part of the diffuser directly.
- Rotate the bottle counter-clockwise to remove it.




Step 2: Add the Fragrance oil

- Fill the bottle with your favourite fragrance oil.



Step 3: Install the bottle and upper part

- Put the upper part directly in the diffuser.



Step 4: Power On the Diffuser

- Connect the device with the USB-C and adapter.
- Use the remote controller to turn on the device, or press the power button to turn on.

Please note: in the default settings for the diffuser, it will emit scent for 30 seconds and then pause for 180 seconds. This cycle will continue for 8 hours, after which the device will turn off automatically.

CHARGING GUIDE



Method 1



Method 2

Method 1: Charge power via type-C cable directly.
Method 2: Charge power via wireless charging base.

LIGHT INDICATOR / DEVICE FUNCTION



The power button on the front of the device works as both a power button and a control for misting and timer settings once the device is turned on.

1. In order to turn the device on please press the power button.

As mentioned in the instructions to use section, in the default setting, the device will release scent for 30 seconds and then pause for 180 seconds.
This cycle will continue for 8 hours, after which the device will turn off automatically.

2. To control the misting and device timer using the power button, follow these steps:

Misting Control:
After the device is turned on, press the power button once to adjust the mist settings:

- When the device is turned on, the mist setting is LOW, mist scent 30s, pause 180s.
- Press once: the mist setting is MED, mist scent 30s, pause 120s.
- Press once again: the mist setting is HIGH, mist scent 30s, pause 60s.

Timer Settings:
After the device is turned on, press the power button twice to adjust the timer setting, This setting allows the device to cycle through the misting setting for an extended period of time until the device automatically powers off.

- **Press twice: 1 hour timer setting.** The screen on the front of device will display 1H. The device will turned off automatically after 1 hour.
- **Press twice again: 4 hours timer setting.** The screen on the front of device will display 4H. The device will turned off automatically after 4 hours.
- **Press twice again: 8 hours timer setting.** The screen on the front of device will display 8H. The device will turned off automatically after 8 hours.

REMOTE CONTROLLER



HOW TO USE REMOTE CONTROLLER

ON/OFF — Press the button to turn on/off the device.

Switch the light color:
blue-red-green-purple-cyan-yellow-white-off light.

LOW — The diffuser will mist scent 30s, pause 180s.

MED — The diffuser will mist scent 30s, pause 120s.

HIGH — The diffuser will mist scent 30s, pause 60s.

1H — 1 hour timer setting. The screen on the front of device will display 1H. The device will turned off automatically after 1 hour.

4H — 4 hours timer setting. The screen on the front of device will display 4H. The device will turned off automatically after 4 hours.

8H — 8 hours timer setting. The screen on the front of device will display 8H. The device will turned off automatically after 8 hours.